

Частотные планы радилюбительских КВ диапазонов (1 и 2 категории)

1.8 МГц	1810.....1838	1838.....1840	1840.....1843	1843.....1900	1900.....2000						
	CW		NARROW DIGITAL		DIGITAL ALL		Favor LSB		Favor FM							
			PSK		RTTY	CW		CW		Favor LSB						
			CW						CW							
3.5 МГц	3500.....3510	3510.....3580	3580.....3585	3585.....3600	3600.....3650	3650.....3700	3700.....3750	3750.....3800
	CW DX 3500-3510		CW		NARROW DIGITAL		DIGITAL ALL		CW		DIGITAL ALL		CW		CW	
			CW DX RDA 3520		PSK		RTTY		SSTV 3735		DX RDA 3650 LSB		DX IOTA 3755 LSB		DX RDA 3780 LSB	
			CW DX IOTA 3530		SIM 3582.0		OLIVIA 16/500 3584.0				Favor LSB				DX 3775-3800	
			CW QRP 3560		CW						CW					
7 МГц	7000.....7040	7040.....7050	7050.....7060	7060.....71757200							
	CW		NARROW DIGITAL		DIGITAL ALL		ALL									
	CW DX RDA 7020		PSK		RTTY		ROS 7050USB		JT65A 7076; JT9 7079		SSTV 7165					
	CW DX IOTA 7030		OLIVIA 16/500 7043.25		SIM 7045.0				CW							
	CW QRP 7030		CW						Favor LSB		DX 7175-7200					
10 МГц	10100.....10140	10140.....10150												
	CW		NARROW DIGITAL													
	CW DX IOTA 10115		PSK		RTTY											
	CW QRP 10116		JT65A 10139; JT9 10141		APRS 10147USB											
	CW DX RDA 10120		OLIVIA 16/500 10142.25		CONTESTIA 10142.5											
			SIM 10142.0		MFSK16 Sched 10141,10144											
			CW													
14 МГц	14000.....14070	14070.....14080	14080.....14099	14099.....14101	14101.....14103	14101.....14112	14112.....14125	14125.....14350
	CW		NARROW DIGITAL		BEACONS				ALL		CW		SSTV 14230		CW	
	CW DX RDA 14020		PSK		RTTY				ROS 14101		OLIVIA 32/1000 14105.5,				CW	
	CW DX IOTA 14040		CW						ROS 14102		14106.5, 14107.5				DX RDA 14180+-5 kHz USB	
	CW QRS 14055		JT65A 14076; JT9 14079		MFSK16 *Sched 14077				APRS 14103LSB						DX 14190-14200 USB	
	CW QRP 14060		OLIVIA 16/500 14073.5		OLIVIA 16/500 14077.65				CW						DX IOTA 14260 USB	
			SIM 14072.5						Favor USB							
18 МГц	18068.....18095	18095.....18100	18100.....18102	18102.....18105	18105.....18109	18111.....18120	18120.....18168		
	CW		NARROW DIGITAL		ALL		ALL		ALL		CW		CW			
	CW DX RDA 18080		RTTY		PSK		RTTY		CW		ROS 18111		DX RDA 18128 USB			
	CW QRP 18086		CW DX IOTA 18098		JT65A 18102; JT9 18105		SIM 18102.0				CW		DX IOTA 18160 USB			
			CW								Favor USB					
21 МГц	21000.....21070	21070.....21080	21080.....21110	21110.....21120	21120.....21149	21149.....21151	21151.....21450		
	CW		NARROW DIGITAL		DIGITAL ALL		NARROW DIGITAL		BEACONS		SSTV 21340		CW			
	CW DX RDA 21020		CW DX IOTA 21040		PSK		RTTY		ROS 21115		CW		DX RDA 21180 USB			
			CW QRS 21055		OLIVIA 8/250 21073		SIM 21082.0		CW				DX IOTA 21260 USB			
			CW QRP 21060		CONTESTIA 21072, 21074		CW						Favor USB			
			JT65A 21076; JT9 21079		CW											
24 МГц	24890.....24915	24915.....24920	24920.....24925	24925.....24929	24929.....24931	24931.....24940	24940.....24990		
	CW		NARROW DIGITAL		BEACONS		ALL		CW		CW		CW			
	CW QRP 24906		RTTY		PSK						CW		DX IOTA 24950 USB			
	CW DX RDA 24910		SIM 24916.0		RTTY								DX RDA 24980 USB			
			CW DX IOTA 24920		JT65A 24920		CONTESTIA 24926.5						Favor USB			
			CW		CW		CW									
28 МГц	28000.....28010	28010.....28080	28070.....28120	28120.....28190	28190.....28199	28199.....28201	28201.....28300	28300.....28320
	CW		CW		NARROW DIGITAL		CW		BEACONS		DIGITAL ALL		Favor USB			
			CW DX RDA 28020		PSK		SIM 28122.0						CW			
			CW DX IOTA 28040		RTTY 28080.....	28150									
			QRS CW 28055		JT65A 28076; JT9 28079		CONTESTIA 28123									
			QRP CW 28060		CW											