

Частотные планы радиолюбительских KB диапазонов (1 и 2 категории)

* Согласно Приложению №2 к Решению ГРЧЦ от 10 марта 2011 года № 11-11-03.

1.8 МГц	1810.....1838	1838....1840	1840.....1843	1843.....1900	1900.....2000
	CW		NARROW DIGITAL	DIGITAL ALL			Голос LSB		Голос LSB	
			PSK	RTTY					Голос AM	
			CW	CW			CW		CW	
3.5 МГц	3500.....	3510.....	3510.....	3580.....	3580.....	3585.....	3600.....	3603.....	3650.....	3750.....
	CW		CW	NARROW DIGITAL			Голос LSB		Голос LSB	
	DX	CW/DX RDA 3520		PSK			RTTY	DIGITAL ALL	QRP 3690 LSB	DIGITAL ALL
		CW/DX IOTA 3530		SIM 3582.0		OLIVIA 16/500 3584.0		SSTV 3735		DX IOTA 3735 LSB
		CW QRP 3560		CW		CW		DX RDA 3650 LSB	PAC 3760	DX RDA 3780 LSB
							CW		CW	
7 МГц	7000.....7040	7040.....7050	7050.....7060	7060.....7175	7175.....	7200
	CW		NARROW DIGITAL	DIGITAL ALL			Голос LSB		Голос LSB	
		CW/DX RDA 7020		PSK		RTTY	ROS 7050USB	ALL		DX
		CW/DX IOTA 7030		OLIVIA 16/500 7043.25		SIM 7045.0		QRP 7090 LSB	SSTV 7165	ALL
		CW QRP 7030		CW		CW		JT65A 7076	PAC 7090, 7110 LSB	
								JT9 7079		
10 МГц	10100.....10140	10140.....10150						
	CW		NARROW DIGITAL							
		CW/DX IOTA 10115		PSK		RTTY				
		CW/DX RDA 10120		JT65A 10139; JT9 10141		APRS 10147USB				
				OLIVIA 16/500 10142.25		CONTESTIA 10142.5				
				SIM 10142.0		MFSK16 10141,10144				
		CW QRP 10116		CW						
14 МГц	14000.....	14070.....	14070.....	14080.....	14080.....	1409.....	14099.....	14101.....	14103.....	14101.....
	CW		NARROW DIGITAL	BEACONS				Голос USB		Голос USB
	CW/DX RDA 14020		PSK	RTTY				DIGITAL ALL	DX RDA 14180+5	DX IOTA 14260
	CW/DX IOTA 14040		JT65A 14076; JT9 14079	MFSK16 *Sched 14077				ROS 14101	OLIVIA 32/1000 14105.5,	SSTV 14230
	CW QRS 14055	OLIVIA 16/500 14073.5	OLIVIA 16/500 14077.65					ROS 14102	14106.5, 14107.5	PAC 14292,14300 USB
		SIM 14072.5						APRS 14103.5B		
		CW QRP 14060		CW				CW		CW
18 МГц	18068.....18095	18095.....	18100.....	18100.....	18102.....	18102.....	18105.....	18105.....	18109.....
	CW		NARROW DIGITAL					Голос USB		Голос USB
		CW/DX RDA 18080		RTTY		PSK	RTTY	ALL		DX RDA 18128
				CW DX IOTA 18098		JT65A 18102; JT9 18105	SIM 18102.0	ROS 18111		DX IOTA 18160
		CW QRP 18086		CW				CW		CW
21 МГц	21000.....21070	21070.....	21080.....	21080.....	21110.....	21110.....	21120.....	21120.....	21149.....
	CW		NARROW DIGITAL	DIGITAL ALL		NARROW DIGITAL	BEACONS		Голос USB	
	CW/DX RDA 21020		CW/DX IOTA 21040	PSK		RTTY	ROS 21115		DX RDA 21180	DX IOTA 21360
				OLIVIA 8/250 21073		SIM 21082.0			SSTV 21340	PAC 21360 (план)
				CONTESTIA 21072, 21074						
		CW QRS 21055		JT65A 21076; JT9 21079						
		CW QRP 21060		CW		CW		CW		CW
24 МГц	24890.....	24915.....	24915.....	24920.....	24920.....	24925.....	24929.....	24929.....	24931.....	24931.....
	CW		NARROW DIGITAL	BEACONS		Голос USB		Голос USB		Голос USB
	CW QRP 24906		RTTY	PSK				ALL	DX IOTA 24930	DX RDA 24980
	CW/DX RDA 24910		SIM 24916.0		RTTY					
		CW/DX IOTA 24920		JT65A 24920		CONTESTIA 24926.5				
				CW				CW		CW
28 МГц	28000.....	28010.....	28010.....	28080.....	28070.....	28120.....	28190.....	28190.....	28199.....	28201.....
	CW		CW	NARROW DIGITAL				BEACONS		Голос USB
		CW/DX RDA 28020		PSK		SIM 28122.0				Голос USB
		CW/DX IOTA 28040		RTTY 28080.....		28150.....				DIGITAL ALL
		CW QRS 28055		JT65A 28076; JT9 28079		CONTESTIA 28123				
		CW QRP 28060		CW		CW				CW
28 МГц	28320.....	28600.....	28600.....	28700.....	28700.....	28920.....	28920.....	29300.....	29300.....	29510.....
	Голос USB		Голос USB		Голос USB		Голос FM, сетка 10 кГц	SATELLITES		Голос FM, сетка 10 кГц
	QRP 28360 USB		SSTV 28675-28685		Голос AM		Голос FM, сетка 10 кГц			FM call - 29600
	DX IOTA 28460, 28560 USB				DIGITAL ALL					
	DX RDA 28580 USB									Голос USB
					CW					CW